


120V, 60Hz, 15A
POWER SUPPLY

WIRING DIAGRAM
E48WV12EPS
E488WV120S



CAUTION: DISCONNECT POWER SUPPLY AT THE
FUSE BOX BEFORE SERVICING THIS EQUIPMENT.

NOTE: E48WV12EPS
ONLY HAS TWO HALOGEN LIGHTS